

Operating Instructions. Safety instructions

WARNING

TO REDUCE FIRE OR SHOCK HAZARD, DO NOT EXPOSE THE UNIT TO RAIN OR MOISTURE. TO AVOID ELECTRICAL SHOCK, DO NOT OPEN THE CABINET.

CAUTION

For your protection, please read these safety instructions completely before operating the appliance, and keep this manual for future reference.

Carefully observe all warnings, precautions and instructions on the appliance, or the one described in the operating instructions and adhere to them.

SAFETY INSTRUCTIONS

POWER SOURCES

This charger should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of electrical power supplied to your home, consult your dealer or local power company.

CLEANING

Unplug the charger from the wall outlet before cleaning or polishing it. Do not use liquid cleaners or aerosol cleaners. Use a cloth lightly dampened with a little bit water for cleaning the exterior of the set.

WATER AND MOISTURE

Do not use power-line operated sets near water - for example, near a bathtub, shower, washbowl, in a wet basement, or near a swimming pool, etc.

FOUDRE

Bien que ce chargeur soit muni d'un parafoudre, d'une façon générale et par mesure de sécurité, débranchez le chargeur de la prise secteur en cas d'orage ou si vous n'utilisez pas le chargeur pendant longtemps. Le chargeur ne risquera pas d'être endommagé par la foudre ou une surtension.

OVERLOADING

Even if the charger got his own overvoltage protection, do not overload wall outlets, extension cords or convenience receptacles beyond their capacity, since this can result in fire or electric shock.

REPAIR

Do not attempt to repair the charger yourself as opening or removing the cover exposes you to dangerous voltages or other dangers. Always use qualified personnel to all your repairs.

MARKING LABEL



This product with the CE marking complies with both the EMC Directive and Low Voltage Directive issued by the Commission of the European Community.

Compliance with these directives implies conformity to the following European standards:

- 2014/35/EU (LVD)
- EN 55032:2015/AC:2016-07
- EN 55035:2017
- RoHS Directive 2011/65/EU amendment directives2015/863/EU (RoHS 2.0)
- EMC Directive 2014/30/EU



Disposal of Waste Electrical and Electronic Equipment for business use (Applicable in the European Union and other European countries with separate collection systems) This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable take-back scheme for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact IXT EUROPE or visit green-e Europe's web : green-e.fr.



This product is intended for use in the following Electromagnetic Environment: E1 (residential)



The devices associated with this symbol are protected by double insulation and do not require any safety connection to earth (ground).



The charging efficiency of the charger is level 6. This is the highest level which guarantees the lowest power consumption for the best possible charge of the device.

2 YEAR LIMITED WARRANTY

This warranty will not apply if, according to the exclusive GROUPE H4 criterion, the charger has damage caused by traffic, handling, storage, accidents, abuse or misuse, or if it has been installed, used or handled improperly. in the product safety manual, if it has been modified in any way, or if the serial number has been deleted or is illegible, or repaired by a person not authorized by GROUPE H4, will void this warranty.